

## MULTI-PURPOSE WALLPAPER ADHESIVE

### ANAGLYPTA™

A multipurpose wallpaper adhesive, suitable for many types of wallpaper

#### **HOW TO USE**

Always follow the manufacturers' instructions when hanging wallpaper.

Remove any old wallpaper from the wall or ceiling and ensure the base surface is clean, dry and slightly absorbent.

Surfaces may need to be sized, especially absorbent surfaces such as new plaster (see mixing chart for size mixing guidance).

We recommend preparing surfaces with lining paper for best results, especially important when plaster has visible defects such as cracks or damage.

Measure out the correct volume of water into a clean bucket and sprinkle the contents into the water whilst stirring briskly for 20 seconds. Allow to stand for 2 minutes.

#### **HANGING STANDARD WALLPAPERS**

Check the wallpaper label before commencing and ensure that the wallpaper is compatible with the adhesive. Apply the adhesive to the pre-cut lengths of wallpaper using a paste brush or roller on a pasting table. Use the adhesive generously working from the centre outwards, ensuring that the edges are well covered. Loosely fold the pasted strips with the pasted sides together, allow to soak for the specified time before hanging the wallpaper. For any paintable wallpaper, we advise the addition of up to 400ml PVA, in place of the same volume of water.

#### **HANGING PASTE-THE-WALL WALLPAPERS**

Check the wallpaper label carefully before commencing and ensure that the wallpaper is compatible with the adhesive.

For such wallpapers the paste can be applied directly to the wall using a roller designed for this purpose or a paste brush. Apply the paste to an area sufficient for slightly more than one strip at a time. The wallpaper can then be applied directly to the wall. When hanging 'paste-the-wall' wallpapers, the paper can also be hung using the same method as for standard wallpaper if preferred but soaking is not necessary. Adhesive performance of this product can be dramatically improved by adding circa 400ml of PVA to the flake adhesive mix, in place of the same volume of water. Alternatively for a superior adhesive quality you may wish to try Anaglypta Ultra adhesive. If in doubt please consult the wallpaper manufacturer.

#### **TIPS**

Take care when using a seam roller or spatula on relief wallpapers as even light pressure can flatten the surface until the product is dried out – for these types of products a wallpaper brush is recommended. Use a wallpapering brush to smooth out the seams if in doubt.

Take care to keep the decorating side of the wallpaper free of paste. Wipe off excess adhesive immediately using a damp sponge to minimise the risk of staining.

The bond strength can be improved by adding PVA adhesive to the mix, especially useful if using heavy-weight or paintable wallpapers, or working in humid environments.

For ceilings it is recommended to use the paste at lower dilutions as shown in the mixing table.

### **CAUTION**

Do not digest. This product contains a fungicide to protect this natural starch from mould growth. Keep the product out of reach of children and animals at all times. Be sure to wash hands thoroughly after use.

APPLICATION	QUANTITY OF COLD WATER TO USE PER SACHET		APPROXIMATE COVERAGE
	PINTS	LITRES	
NORMAL WALLPAPERS INCLUDING WOODCHIP	12	7	8-10 ROLLS
VINYL WALLCOVERINGS, WASHABLES	10	5.5	6-8 ROLLS
TEXTURED AND BLOWN VINYL	8	4.5	3-5 ROLLS
PASTE THE WALL WALLCOVERINGS	8	4.5	2-4 ROLLS
EMBOSSSED PAPERS	8	4.5	2-4 ROLLS
HEAVY EMBOSSSED PAPERS	7	4	2-3 ROLLS
FOR USE AS A SIZE	16	9	100 M2

BARCODE