

ThermaWrap

Self-Adhesive Garden Insulation

REFLECTIVE ALUMINIUM FOIL INSULATING FOR ALL YOUR GARDEN NEEDS.
BOOSTS THE GROWING POWER OF YOUR PLANTS, BY REFLECTING THE SUNS RAYS.

INSTALLATION

> General Fixing:

Firstly, measure your intended application and calculate the amount of insulation required.

Before applying ThermaWrap self-adhesive garden insulation, ensure the surface of the green house is clean and free from any debris or dirt (it is advised to clean the surface before installation).

Step 1 – Starting at the bottom, roll the insulation out across the surface, once in position peel the easy peel backing from the self-adhesive tape and apply pressure to the surface (this will ensure the tape bonds to the surface), once in position cut the material at the end. Any window openings, handles, doors, etc should be cut around to ensure access.

Step 2 – Apply the next layer of insulation following the instructions shown in step 1, however this time ensure there is an overlap of 50mm.

> Cutting:

Thermawrap can be cut using a craft knife or sharp pair of scissors.

> Tape Fixing:

Clean the surface of all loose debris, position the insulation, remove the easy peel backing and apply pressure to the back of the insulation.

> With built in self adhesive tape.

> Thermawrap product range.



For more information about our full range visit: ybsinsulation.com/diy