



*Preventavent vents are simply designed to cover a buildings air vent ensuring rodents can't access the property this way.*

**1** Locate all air bricks around the property and ensure you have the correct size preventavent to cover the entire vent.

**2** IF INSERTING WITH SCREWS:  
Drill 4 holes in line with each corner of the preventavent and insert a red wall plug, using 5.5mm screws, drill through the pre-drilled holes to secure the Preventavent against the vent.

**3** IF APPLYING WITH ADHESIVE:  
Using a strong adhesive suitable for exterior use, apply a bead to the back edge of the Preventavent, press against the airbrick vent and hold in place until set.

