

Instruction Manual ZN-32302 Floor Stand

Fig.A




Fig.B





Fig.C



**NB: TO BE READ
IN CONJUNCTION
WITH INSTRUCTIONS
SUPPLIED WITH HEATER

(HEATER SOLD SEPARATELY)**

Part List

No.	Part Name		
1	Heater	9	Base Cover
2	Heater Screw	10	Base
3	Straight Tube	11	Washer
4	Outer Fastener	12	L Screw
5	Upper Tube	13	Cord Clip
6	Screw		
7	Middle Tube		
8	Lower Tube		

If you receive this item with parts broken or missing, please telephone:

0333 0050077

Please have ready your name, address, tel. no., product reference, where purchased and parts required. An answering service is in operation outside office hours and during busy periods. We regret that we are unable to give advice on internal house wiring.
Cascade Holdings Ltd, Gorse Mill, Gorse Street, Chadderton, Oldham. OL9 9RJ

HEATER SOLD SEPARATELY

Caution:

- Children aged from 3 years and less than 8 years should only switch the appliance on or off provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years should not plug in, regulate and clean the appliance or perform any user maintenance.
CAUTION -- Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
- When used with a Heater, the stand must not be located immediately below a socket-outlet.
- When used with a heater do not use this stand in the immediate surroundings of a bath, shower or swimming pool.
- When used with a heater, do not place the unit close to a curtain and/or other flammable objects, otherwise there will be a danger of catching fire.
- When used with a heater do not cover the unit with anything during operation or a short time after it has been shut down.
- Do not use this unit in a place where causticity or volatile air exists, i.e. dust, steam, gas, etc.
- When used with a heater the unit must be placed with a clearance of at least 150cm.
- The unit must be securely placed on a horizontal and flat surface.
- When used with a heater the unit is at high temperature during operation. It remains hot for a after shut down. Potential danger would occur when touching it during this period.
- The unit must be handled with care, avoid any vibration, bumping or hitting.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory mental capabilities, or lack of experience and knowledge, unless they have been given supervisory instruction concerning use of the appliance by a person responsible for their safety.
- When used with a heater the unit is for outdoor use only. It is not recommended for use in buildings such as greenhouses, barns or stables where there could be flammable dust.
- When used with a heater, the head of the unit is at high temperature during operation. Unplug the heater and wait till it cools before moving.

WARNING:

This floor stand must always be positioned on a flat even secure surface. When used with a heater, do not use it in an area occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.

Preparation:

- Prepare a cross head screw driver.
- Read this instruction manual carefully before installation and use. Keep this instruction manual proper and safe place for future use in case needed.

Installation:

- As shown in Fig. A, put Lower Tube (#9) through the hole of Base (#10) and Base Cover(#14) make sure the end of Lower Tube with welded plate is downward, and the extra tongue is located in the sin the base. Fix Lower Tube and Base together with Washer (#11) & L Screw (#12).
- As shown in Fig. A, Install Middle Tube (#8) on top of Lower Tube. Pullout Straight Tube (#5) up from inside of Upper Tube (#7). Screw Outer Fastener (#6) clockwise to lock it. Then install Upper Tube (#7) on Middle Tube (#8).
- As shown in Fig. A, Insert Straight Tube (#5) into the hole on bottom of Control Box (#1). Then fix together with Screw (#13).
- As shown in Fig. A, Turn Outer Fastener (#6) counter-clockwise and adjust the unit to a desired height Then tighten Fastener (#6).
- As shown in Fig. A, after step1~step4, fix Cord Clip(#3) both to the hole on Tube(#7) and Tube with Screw(#4)
- Clip Power Supply Cord with Cord Clips (#3). Fix them onto the tubes..

Cleaning:Unplug the unit before cleaning. It should be wiped with wet cloth. Do not use too much water.