


工厂型号		客 户 型 号		改稿日期	制 稿 人
FH-388Q		62624		2026/5/6	myl
尺 寸		材 质			印 刷 颜 色
145x210mm		双胶纸，具体以采购合同为准			单色
备 注		/		/	
注：印刷前请与此文件仔细核对。如有疑问，请及时与我联系！ (如未发源文件，请对照“改稿日期”“版本”信息，对上再进行安排)					

Original User Instructions.


TOOLSTATION

2kW UPRIGHT FAN HEATER

SKU: 62624
Domestic Use Only



WHAT'S IN THE BOX



x 1

User's manual x 1

If you do not have all these items, please contact:
www.toolstation.com/contact
Telephone 0808 100 7211 Mobile friendly 0330 333 3303
Email info@toolstation.com

PLEASE KEEP THESE INSTRUCTIONS FOR FURTHER REFERENCE

SPECIFICATION

- 220-240V~50Hz
- 2 heat settings: 1000W/2000W
- Power indicator light
- Fan ventilation mode
- Adjustable thermostat
- Overheat protection
- Double thermal automatic cut-out

TECHNICAL DATA

Model	FH-388Q
Rated Voltage	220-240V ~50Hz
Rated Power Rate	1800-2000W
Plug	BS plug
Power Cord Length(mm)	1300
Power Cord Spec	H05VV-F 2x0.75mm2
Dimension(H x L x W-mm)	220x135x255
Net Weight(g)	1000

EXPLANATIONS AND SYMBOLS, CAUTIONS AND WARNINGS



DO NOT COVER


HEALTH AND SAFETY

- The heater carries the warning symbol indicating that it must not be covered.
- **WARNING:** In order to avoid overheating **DO NOT** cover the heater.
- **DO NOT** use the heater in the immediate surroundings of a bath, a shower or a swimming pool.
- **DO NOT** use this heater if it has been dropped.
- **DO NOT** use if there are visible signs of damage to the heater.
- USE this heater on a horizontal and stable surface.
- **DO NOT** cover or obstruct the air inlet and outlet openings in any way.
- **DO NOT** insert any object through the heat outlet or air intake grilles of the heater. Keep combustible materials such as drapes and other furnishings clear from the front, sides and rear of the heater. Do not use heater to dry your laundry.
- **DO NOT** place the heater on carpets.
- **DO NOT** operate the heater with the mains lead overhanging the front outlet grille. Keep the mains lead away from the hot body of the heater.
- **WARNING:** Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.
- **WARNING:** To reduce the risk of fire, keep textiles, curtains, or any other flammable material a minimum distance of 1 m from the air outlet.
- **WARNING:** The plug cut off the mains lead with conductors exposed will be dangerous if inserted into a socket.
- **IMPORTANT:** If the mains lead of this appliance is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- **DO NOT** position the heater in front of, or immediately below a socket-outlet.
- The plug is fitted with a 10 Amp fuse. When replacing, use only a fuse approved to BS1362 and carrying the relevant approval Mark. Never use the plug with the fuse omitted.

- Suitable for indoor use only.
- This product is only suitable for use in living areas (not for areas constantly subject to moisture).
- **IMPORTANT:** Always switch off at the socket and remove the plug when not in use.
- Always unplug the heater when moving it from one location to another.
- **DO NOT** cover or obstruct any of the grilles or the air intake openings of the heater.
- Always ensure that the heater is placed on a firm level surface.
- Ensure that the heater is not positioned close to curtains or furniture as this could create a fire hazard.
- **DO NOT** use the heater in areas where flammable liquids are stored or where flammable fumes may be present.
- **DO NOT** run cord under carpeting and **DO NOT** cover cord with throw rugs, runners or the like. Arrange cord away from traffic area and where it will not be tripped over.
- **DO NOT** operate with a damaged cord or plug, or after the heater malfunctions, has been dropped, or damaged in any manner.
- **DO NOT** use of an extension cord as this may overheat and cause a risk of fire.
- In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is switched on and off remotely.
- The appliance is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they **DO NOT** play with the appliance.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be performed by children without supervision.

- Children of less than 3 years should be kept away unless continuously supervised.
- Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
- **CAUTION- SOME PARTS OF THIS PRODUCT CAN BECOME VERY HOT AND CAUSE BURNS. PARTICULAR ATTENTION HAS TO BE GIVEN WHERE CHILDREN AND VULNERABLE PEOPLE ARE PRESENT.**

ASSEMBLY AND USE



- **Check if the power wire is under good condition.**
1. The product adopts 220-240V AC power supply, before use, please confirm if the rated current of the power socket meets the local requirements with safe grounding device, otherwise, please replace it with the qualified socket.
2. Put the machine on the flat place, at least the surface below the base of the heater must be flat.
- **Adjustable thermostat control knob**
Insert the plug into the power socket, then turn the adjustable thermostat control knob clockwise, when hearing the "click" sound (it means the temperature controller is on), adjust the adjustable thermostat control knob to the desired temperature level.
- **Heat setting knob**
Turn the heat setting knob to select between 3 functions:
Fan only ()
Low 1000 W (I),
High 2000 W (II).

- **Turn off the heater**
1. Turn the heat setting knob to OFF position.
2. Turn the adjustable thermostat control knob anticlockwise to the initial position.
3. Remove the power plug, store the heater after the entire machine has become cool.
- **Safety Protection**
Overheat protection: When the temperature in the heater is too high due to abnormality in the use environment or improper use, the thermostat device can automatically cut off the power and the heater stops working. After the whole heater is cooling, the heater can return to the normal use after removing the abnormality.

CARE AND CLEANING

- Disconnect the power and allow the heater to cool.
- Clean the exterior only of this heater with a soft dry cloth.
- Do not use any chemical or abrasive cleaners.
- When the heater is not used for long periods of time, it should be protected from dust and stored in a clean dry place.

TROUBLE SHOOTING

Use this section to help you to try and solve any problems you may have:

PROBLEM	POSSIBLE CAUSES	REMEDIES
Although the heater is plugged In and switched on, the heater does not start working.	The plug may not be properly connected.	Check that the plug is properly inserted into the socket.
The machine stops suddenly while it is working.	The temperature has exceeded the threshold of the thermal cut-off.	Let the heater cool down before use. Ensure that the vents are not clogged with dust or fluff.

NOTE: IF YOU EXPERIENCE A PROBLEM WITH YOUR HEATER, PLEASE DO NOT ATTEMPT TO OPEN OR REPAIR THE HEATER YOURSELF. DOING SO MAY VOID THE WARRANTY AND COULD CAUSE DAMAGE OR PERSONAL INJURY. IF THE PROBLEM STILL PERSISTS, PLEASE CONTACT US BY REFERRING TO THE SERVICE & SUPPORT INFORMATION ON THE FOLLOWING PAGE.

DECLARATION OF CONFORMITY



Product Code: 62624 (Model: FH-388Q)
Product Description: 2kW FAN HEATER

1. Toolstation Limited (company number 04372131)
Toolstation is a Travis Perkins company

2. Object of the declaration:

The object of the declaration described above is in conformity with the relevant Community harmonisation legislation:

- The Electrical Equipment (Safety) Regulations 2016 (2014/35/EU)
- Electromagnetic Compatibility Regulations 2016 (2014/30/EU)
- The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012 (2011/65/EU&(EU)2015/863)

3. References to the relevant standards used or references to the specifications in relation to which conformity is declared:

EN 60335-1
EN 60335-2-30
EN 62233
BS EN IEC 55014-1
BS EN IEC 55014-2
BS EN 61000-3-3
BS EN IEC 61000-3-2

4. Additional information:
Signed for and on behalf of Toolstation Limited

ENVIRONMENTAL INFORMATION



When your heater comes to the end of its life or you choose to update or upgrade it by replacing it, please do not dispose of it with your normal household waste. Please recycle where facilities exist. When you need to dispose of this heater, check with your retailer or local authority for suitable options. Regulations encourage the recycling of Waste from Electrical and Electronic Equipment (DIRECTIVE 2012/19/EU OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 4 July 2012 on waste electrical and electronic equipment (WEEE)).

ENERGY USE INFORMATION

Model(s): SKU 62624/ Model FH-388Q					
Item	Symbol	Value	Unit	Item	Unit
Heat output			Type of heat output/room temperature control (select one)		
Nominal heat output	P _{nom}	1,800-2,000	kW	Single stage heat output and no room temperature control	[no]
Minimum heat output (indicative)	P _{min}	1,000	kW	Two or more manual stages, no room temperature control	[no]
Maximum continuous heat output	P _{max,c}	2,000	kW	With mechanic thermostat room temperature control	[yes]
Power consumption			With electronic room temperature control		
In off mode	P _o	0,00	W	Electronic room temperature control plus day timer	[no]
In standby mode	P _{stn}	0,00	W	Electronic room temperature control plus week timer	[no]
In idle mode	P _{idle}	0,00	W	Other control options (multiple selections possible)	[no]
In network standby	P _{stn}	0,00	W	Room temperature control, with presence detection	[no]
Standby mode with display information or status NO				Room temperature control, with open window detection	[no]
Seasonal space heating energy efficiency in active mode	η _{s,son}	44,7	%	With distance control option	[no]
				With adaptive start control	[no]
				With working time limitation	[no]
				With black bulb sensor	[no]
				With self-learning functionality	[no]
				With control accuracy	[no]
Contact details	Toolstation Limited (company number 04372131)				

GUARANTEE

Toolstation products deliver reliable service for normal, household use in domestic settings. All Toolstation products are individually tested before leaving the factory. If you are a consumer and you experience a problem with your Toolstation product, which is found to be defective due to faulty materials or workmanship within the Guarantee Period, this Toolstation Guarantee will cover repair or - at the discretion of Toolstation - replacement with a functionally equivalent Toolstation product. Your product is under guarantee for 1 year from the date of purchase or the date of delivery of the product, if later.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, parts, knobs, or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in this manual.
- It must be used solely for domestic purpose.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- Specifications are subject to change without notice.
- The manufacturer disclaims any liability for the incidental or consequential damages.
- The guarantee is in addition to, and does not diminish your statutory or legal rights.

CUSTOMER SUPPORT

www.toolstation.com/contact
Call us 0808 100 7211
Mobile friendly 0330 333 3303
Email: info@toolstation.com

Made in China