

145.00 mm

WESSEX
electrical**TOOLSTATION**


Original User Instructions

Oil-Filled Radiator (Domestic Use Only)

SKU: 76732

SKU: 52406

SKU: 73102, 27906



This product is only suitable for well insulated spaces or occasional use.

**READ BEFORE USE****PLEASE KEEP THESE INSTRUCTIONS FOR FURTHER REFERENCE**

CONTENTS

- WHAT'S IN THE BOX----- 3
- TOOLS REQUIRED----- 3
- SPECIFICATIONS----- 4
- EXPLANATIONS AND SYMBOLS, CAUTIONS AND WARNINGS----- 5
- IMPORTANT SAFETY WARNINGS----- 6
- PRODUCT DESCRIPTION AND IDENTIFICATIONS----- 9
- ASSEMBLY AND OPERATING INSTRUCTIONS----- 10
- CARE AND CLEANING----- 12
- TROUBLESHOOTING----- 12
- DECLARATION OF CONFORMITY / PERFORMANCE----- 13
- ENVIRONMENTAL INFORMATION----- 14
- ENERGY USE INFORMATION----- 15
- WARRANTY----- 18
- CUSTOMER SUPPORT----- 18

WHAT'S IN THE BOX



Oil-filled radiator body x 1



User instruction manual x 1



Foot with castors x 2



Foot fixing U bolt x 1



Wing nut x 4

If you DO NOT have all these items, please contact:

- www.toolstation.com/contact
- Telephone 0808 100 7211 Mobile friendly 0330 333 3303
- Email info@toolstation.com

TOOLS REQUIRED

- N/A

SPECIFICATIONS

SKU: 76732 / Model: CYBL20-7

- 220-240V~50Hz
- 3 heat settings
- 600W/900W/1500W
- Adjustable thermostat
- Tip-over safety protection
- Overheat protection
- Cable storage

SKU: 52406 / Model: CYBL20-9

- 220-240V~50Hz
- 3 heat settings
- 800W/1200W/2000W
- Adjustable thermostat
- Tip-over safety protection
- Overheat protection
- Cable storage

SKU: 73102,27906 / Model: CYBL20-9T

- 220-240V~50Hz
- 3 heat settings
- 800W/1200W/2000W
- Adjustable thermostat
- Tip-over safety protection
- Overheat protection
- Cable storage
- 24 hours timer

TECHNICAL DATA

SKU/Model	76732/CYBL20-7	52406/CYBL20-9	73102,27906/ CYBL20-9T
Rated Voltage	220-240V~ 50Hz	220-240V~50Hz	220-240V~50Hz
Rated Power	1500W	2000W	2000W
Plug	BS 1363 plug	BS1363 plug	BS1363 plug
Power Cord Length(mm)	1800mm	1800mm	1800mm
Power Cord Spec	H05RN-F 3G0.75mm ²	H05RN-F 3G0.75mm ²	H05RN-F 3G0.75mm ²
Dimension (H x L x W-mm)	635X300X250	635X365X250	635X365X250
Net Weight- Approx.(g)	6300	7700	7740

EXPLANATIONS AND SYMBOLS, CAUTIONS AND WARNINGS



DO NOT COVER



This warning symbol indicates a hazard with an average risk level which, if not avoided, could result in serious injury or damage or death.



The product complies with the applicable European Directives and an evaluation method of conformity for these Directives was done.



UK Conformity Assessed



Class I protection appliance, Earthing connection



WEEE symbol. Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or local store for recycling advice.



IMPORTANT SAFETY WARNINGS




- The heater carries the warning symbol indicating that it must not be covered.
- **WARNING:** In order to avoid overheating **DO NOT** cover the heater.
- **DO NOT** use the heater in the immediate surroundings of a bath, a shower or a swimming pool.
- **DO NOT** use this heater if it has been dropped.
- **DO NOT** use if there are visible signs of damage to the heater. USE this heater on a horizontal and stable surface.
- **DO NOT** cover or obstruct the air inlet and outlet openings in any way.
- **DO NOT** insert any object through the heat outlet or air intake grilles of the heater. Keep combustible materials such as drapes and other furnishings clear from the front, sides and rear of the heater. Do not use heater to dry your laundry.
- **DO NOT** place the heater on carpets.
- **DO NOT** operate the heater with the mains lead overhanging the front outlet grille. Keep the mains lead away from the hot body of the heater.
- **WARNING:** Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.
- **WARNING:** To reduce the risk of fire, keep textiles, curtains, or any other flammable material a minimum distance of 1 m from the air outlet or heat dissipation fins.
- **WARNING:** The plug cut off the mains lead with conductors exposed will be dangerous if inserted into a socket.
- **IMPORTANT:** If the mains lead of this appliance is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- This product must be connected to Earth.
- **DO NOT** position the heater in front of, or immediately below a socket-outlet.
- **DO NOT** leave the heater unattended at any time whilst switched on.
- The plug is fitted with a 10 Amp fuse. When replacing, use only a fuse approved to BS1362 and carrying the relevant approval Mark. **Never** use the plug with the fuse omitted.
- Suitable for indoor use only.

- This product is only suitable for use in living areas (not for areas constantly subject to moisture).
- **IMPORTANT:** Always switch off at the socket and remove the plug when not in use.
- Always unplug the heater when moving it from one location to another.
- **DO NOT** cover or obstruct any of the grilles or the air intake openings of the heater.
- Always ensure that the heater is placed on a firm level surface.
- Ensure that the heater is not positioned close to curtains or furniture as this could create a fire hazard.
- **DO NOT** use the heater in areas where flammable liquids are stored or where flammable fumes may be present.
- **DO NOT** run cord under carpeting and **DO NOT** cover cord with throw rugs, runners or the like. Arrange cord away from traffic area and where it will not be tripped over.
- **DO NOT** operate with a damaged cord or plug, or after the heater malfunctions, has been dropped, or damaged in any manner.
- **DO NOT** use of an extension cord as this may overheat and cause a risk of fire.
- In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is switched on and off remotely.
- The appliance is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they **DO NOT** play with the appliance.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be performed by children without supervision.
- Children of less than 3 years should be kept away unless continuously supervised.
- Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given

supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.

- **CAUTION- SOME PARTS OF THIS PRODUCT CAN BECOME VERY HOT AND CAUSE BURNS. PARTICULAR ATTENTION HAS TO BE GIVEN WHERE CHILDREN AND VULNERABLE PEOPLE ARE PRESENT.**


PRODUCT DESCRIPTION AND IDENTIFICATIONS




ASSEMBLY AND OPERATING INSTRUCTIONS

Assembly

- Before using your new heater, the legs and castors must be fitted.
- The front Leg must be fitted on the control panel; the rear must be fitted between the end two fins for stability. Invert the heater and grip firmly.
- Put the front leg on the control panel, then screws. Hold 'U' bolt around the joint between the end two fins, with the threads protruding from the bottom of the heater.
- There are two additional holes in the legs to accommodate the screws that retain the control panel end. Secure in position using two of the wing nuts.



Assemble front foot with castors



Assemble rear foot with castors

Use

- NOTE: It is normal when the heaters are turned on for the first time or when they are turned on after having not been used for a long period of time the heaters may emit some smell and fumes. This will disappear when the heater has been on a short while.
- Choose a suitable location for the heater, taking into account the safety instructions above.
- Insert the plug into a suitable socket.
- Turn the thermostat control fully clockwise to the maximum setting.
- Turn on using the heat selector switch on the side panel. There are three heat settings: rotate the switch to increase power.
- When the desired room temperature has been reached, turn the thermostat slowly anti-clockwise until the thermostat is heard to click off and the lights on the element switches go out. After this the heater will keep the air temperature in the room at the set level by switching on and off automatically.
- Make small adjustments to more accurately control the temperature.

Only for model with timer: SKU 73102, 27906

1. Regulate the time of timer according to the clock by turning it clockwise (DO NOT TURN IT COUNTER CLOCKWISE).

2. The timer has a small switch; the function is as follow: I= Unit is always ON;



=Timer function is ON.

3. Set the timer to  position. There are 96 small plastic pins on the timer, each correspond to 15 minutes interval. Push outward the pins corresponding to the time you want the heater to turn ON and push inward the pins corresponding to the time you want the heater to turn OFF.


CAUTION: Do not use the timer function unattended.



4. The heater will not operate if timer is set to the  position and the pins are not activated according to the times required.

5. If the heater loses its electricity supply, e.g. Switched off at the mains socket or in the event of a power failure, it should be reset once power has been restored.

6. The indicator light will be on when the timer is set to ON position or the timing function is activated.



CARE AND CLEANING

- Disconnect the power and allow the heater to cool.
- Clean the exterior only of this heater with a soft dry cloth.
- Do not use any chemical or abrasive cleaners.
- When the heater is not used for long periods of time, it should be protected from dust and stored in a clean dry place.

TROUBLESHOOTING

Use this section to help you to try and solve any problems you may have:

PROBLEM	POSSIBLE CAUSES	REMEDIES
Unexpected cracking sounds	This is the normal sound after starting up the product.	Once the heater heats up, the cracking goes away.
Unexpected smell	This is the result of dust or other debris accumulating on the heating element. This is normal during first use and after prolonged storage.	Make sure the product is placed in a good ventilated area. Keep the product switched on, until the smell disappears.
Heater shuts off unexpectedly	Ensure the power cord is plugged into a working socket outlet. Safety function (over heating/ tip over) may have been activated.	Switch off the heater to cool it down and restart.

NOTE: IF YOU EXPERIENCE A PROBLEM WITH YOUR HEATER, PLEASE DO NOT ATTEMPT TO OPEN OR REPAIR THE HEATER YOURSELF. DOING SO MAY VOID THE WARRANTY AND COULD CAUSE DAMAGE OR PERSONAL INJURY. IF THE PROBLEM STILL PERSISTS, PLEASE CONTACT US BY REFERRING TO THE SERVICE & SUPPORT INFORMATION ON THE FOLLOWING PAGE

DECLARATION OF CONFORMITY / PERFORMANCE



1. **Product Models:**
76732 / CYBL20-7
52406 / CYBL20-9
73102 / CYBL20-9T
27906 / CYBL20-9T
2. **Product Description:**
Wessex Oil Radiator 1.5kW
Wessex Oil Radiator 2kW
Wessex 2kW Oil Radiator with 24hr Timer
Wessex Oil Filled Radiator with Timer 2.0kW Black
3. **Name and Address of the Manufacturer (or its authorised representative in the UK):**
Toolstation - company number 04372131.
4. This declaration of conformity is issued under the sole responsibility of Toolstation.
5. The product(s) detailed above is/are in conformity with the following applicable UK legislation and EU harmonisation legislation:
 - Low Voltage Directive - 2014/35/EU (The Electrical Equipment (Safety) Regulations 2016 - SI 2016/1101)
 - Electromagnetic Compatibility - Directive 2014/30/EU (The Electromagnetic Compatibility Regulations 2016 - SI 2016/1091)
 - Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment (RoHS) - Directive 2011/65/EU (The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012 - SI 2012/3032)
 - Ecodesign Directive - COMMISSION REGULATION (EU) 2024/1103 (The Ecodesign for Energy-Related Products Regulations 2010 - SI 2010/2617)
6. References to the relevant harmonised standards and technical specifications:

EN 60335-1
EN 60335-2-30
EN 62233
EN IEC 55014-1
EN IEC 55014-2
EN IEC 61000-3-2
EN 61000-3-3

Signed for and on behalf of Toolstation - company number 04372131.

ENVIRONMENTAL INFORMATION



The symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste for recycling, please contact your local authority, or where you purchased your product.

ENERGY USE INFORMATION

Model(s)	SKU 76732 / MODEL CYBL20-7					
Item	Symbol	Value	Unit		Item	Unit
Heat output					Type of heat input, for electric storage local space heaters	
Nominal heat output	Pnom	1.500	kW		Single stage heat output and no room temperature control	No
Minimum heat output (indicative)	Pmin	0.600	kW		Two or more manual stages, no room temperature control	No
Maximum continuous heat output	Pmax,c	1.500	kW		With mechanic thermostat room temperature control	Yes
Power consumption					Type of heat output / room temperature control	
In off mode	Po	0.00	W		With electronic room temperature control	No
In standby mode	Psm	0.00	W		Electronic room temperature control plus day timer	No
In idle mode	Pidle	0.00	W		Electronic room temperature control plus week timer	No
In network standby	Pnsm	0.00	W		Other control options (multiple selections possible)	
Standby mode with display information or status			No		Room temperature control, with presence detection	No
Seasonal space heating energy efficiency in active mode	$\eta_{S,on}$	85.0	%	No	Room temperature control, with open window Detection	No
					With distance control option	No
					With adaptive start control	No
					With working time limitation	No
					With black bulb sensor	No
This heater is only suitable for well insulated spaces or occasional use.					With self-learning functionality	No
					With control accuracy	No
Toolstation Limited (company number 04372131)						

Model(s)	SKU 52406 / MODEL CYBL20-9				
Item	Symbol	Value	Unit	Item	Unit
Heat output				Type of heat input, for electric storage local space heaters	
Nominal heat output	P _{nom}	2.000	kW	Single stage heat output and no room temperature control	No
Minimum heat output (indicative)	P _{min}	0.800	kW	Two or more manual stages, no room temperature control	No
Maximum continuous heat output	P _{max,c}	2.000	kW	With mechanic thermostat room temperature control	Yes
Power consumption				Type of heat output / room temperature control	
In off mode	P _o	0.00	W	With electronic room temperature control	No
In standby mode	P _{sm}	0.00	W	Electronic room temperature control plus day timer	No
In idle mode	P _{idle}	0.00	W	Electronic room temperature control plus week timer	No
In network standby	P _{nsm}	0.00	W	Other control options (multiple selections possible)	
Standby mode with display information or status			No	Room temperature control, with presence detection	No
Seasonal space heating energy efficiency in active mode	$\eta_{S,on}$	85.0	%	Room temperature control, with open window Detection	No
				With distance control option	No
				With adaptive start control	No
				With working time limitation	No
				With black bulb sensor	No
This heater is only suitable for well insulated spaces or occasional use.				With self-learning functionality	No
				With control accuracy	No
Toolstation Limited (company number 04372131)					

Model(s)		SKU 73102, 27906 / MODEL CYBL20-9T			
Item	Symbol	Value	Unit	Item	Unit
Heat output				Type of heat input, for electric storage local space heaters	
Nominal heat output	P _{nom}	2.000	kW	Single stage heat output and no room temperature control	No
Minimum heat output (indicative)	P _{min}	0.800	kW	Two or more manual stages, no room temperature control	No
Maximum continuous heat output	P _{max,c}	2.000	kW	With mechanic thermostat room temperature control	Yes
Power consumption				Type of heat output / room temperature control	
In off mode	P _o	0.00	W	With electronic room temperature control	No
In standby mode	P _{sm}	0.00	W	Electronic room temperature control plus day timer	No
In idle mode	P _{idle}	0.00	W	Electronic room temperature control plus week timer	No
In network standby	P _{nsm}	0.00	W	Other control options (multiple selections possible)	
Standby mode with display information or status			No	Room temperature control, with presence detection	No
Seasonal space heating energy efficiency in active mode	$\eta_{S,on}$	87.0	%	No	Room temperature control, with open window Detection
				With distance control option	No
				With adaptive start control	No
				With working time limitation	Yes
				With black bulb sensor	No
This heater is only suitable for well insulated spaces or occasional use.				With self-learning functionality	No
				With control accuracy	No
Toolstation Limited (company number 04372131)					

WARRANTY

Toolstation products deliver reliable service for normal, household use in domestic settings. All Toolstation products are individually tested before leaving the factory.

If you are a consumer and you experience a problem with your Toolstation product, which is found to be defective due to faulty materials or workmanship within the Warranty Period, this Toolstation Guarantee will cover repair or - at the discretion of Toolstation – replacement with a functionally equivalent Toolstation product.

Your product is under warranty for 1 year from the date of purchase or the date of delivery of the product, if later.

The warranty is subject to the following provisions:

- The warranty does not cover accidental damage, misuse, parts, knobs, or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in this manual.
- It must be used solely for domestic purpose.
- The warranty will be rendered invalid if the product is re-sold or has been damaged by inexperienced repair.
- Specifications are subject to change without notice.
- The manufacturer disclaims any liability for the incidental or consequential damages.
- The warranty is in addition to, and does not diminish your statutory or legal rights.

CUSTOMER SUPPORT

www.toolstation.com/contact

Call us 0808 100 7211

Mobile friendly 0330 333 3303

Email: info@toolstation.com

Made in China

Imported by Toolstation 04372131.

Wessex Electrical is a Toolstation brand. Toolstation is part of Travis Perkins Trading Company Limited.

