


Basin Mixer Tap

Fitting instructions



85781

Please keep these instructions for future reference.



Contents

Page

- 1. Tools required**
- 2. Parts Supplied**
- 3. Specifications**
- 4. Installation**
- 5. Aftercare**


3
3
3
4
4

Tools required (Tools not supplied)



Parts Supplied

NO.	Description	Qty
1	Tap Body	1
2	Flange	1
3	Sealing Washer	1
4	Fixing Studs	2
5	Rubber Horseshoe Washer	1
6	Metal Horseshoe Washer	1
7	Fixing Nuts	2
8	Braided Connectors	2
9	Waste Body	1
10	Sealing Washer	1
11	Backnut Washer	1
12	Backnut	1



Specifications

The tap is suitable for use at water supply pressures of 0.3 bar (min.) to 5 bar (max.).

It should be installed in compliance with Water Fittings Regulations.


For further details contact your Local Water Authority.

- (a) Identify all components and check pack contents.
- (b) Turn off water mains supply.

Installation

Fitting the mixer tap:

1. Fit Fixing Studs (4) to Tap Body (1) and tighten it.
2. Make sure that Sealing Washer (3) has been fitted to Flange (2). Fit Flange (2) to the Tap Body (1).
3. Screw 2x Braided connectors (8) into Tap Body (1) through the hole of flange, do not over tighten.
4. Locate the tap assembly down through the tap hole in basin.
5. Fit Rubber Horseshoe Washer (5) and Metal Horseshoe Washer (6) onto the Fixing Studs (4). And then fix Fixing Nuts (7) onto the Fixing Studs (4). Do not over tighten.
6. Fit Braided Connectors (8) to the water supply using suitable plumbing joints.
7. Turn on the hot and cold and mains water supply. Check for leaks immediately. It is always advisable at this stage to flush out the system. To do this, open both valves fully and allow water to flow for approx. 1 minute. This will remove any foreign matter within the installation.
8. Finally turn on all the water heating arrangements.



Fitting the basin waste:

1. Fit Waste Body (9) with Sealing Washer (10) through hole in basin. It is advisable at this stage to use small bead of silicone sealant between waste body and basin.
2. Fit Backnut Washer (11) over threaded part of waste body and screw Backnut (12) onto waste body. Do not overtighten.

Aftercare

Whilst modern plating techniques are used in the manufacture of these fittings, the plating will wear if not cleaned properly. The safest way to clean your product is to wipe with a soft damp cloth. Stains can be removed using washing up liquid. All cleaning powders and liquids will damage the surface of your fitting even the non-scratch cleaners.